



## First Time Network Setup

The DMG 7000 software provides a manual configuration override using a local Keyboard, Monitor, and Mouse. The Text-Based menu provides a means to re-configure the network ports. Each menu screen is clearly labeled.

### Set the desired IP for management on Eth0 adapter:

- ✓ Use the up or down key to select Configure Networks and press Enter
- ✓ Use the Enter key to select and Escape key to back out as needed
- ✓ Use the up or down keys to change the numbers inside IP fields

```

+-----+
|           Unit Networking           |
|   Configure Networks               |
|   eth0 Adapter Status              |
| >eth1 Adapter Status               |
+-----+

Press [Left] and [Right] arrow keys to Navigate.
Press [Up] and [Down] arrow keys to Navigate.
Press [Enter] to Confirm your selection.
Press [Esc] to go back a screen.
Press [Number] Keys to input Numbers.
Press [A-Z], [Del] and [Backspace] for Text input.

```

```

+-----+
|           Adapter Config eth0      |
|   IP Mode: Static                  |
|   IP: 10.0.106.3                   |
|   Mask: 255.255.000.000            |
|   Gateway: 10.0.1.3                |
+-----+

Press [Left] and [Right] arrow keys to Navigate.
Press [Up] and [Down] arrow keys to Navigate.
Press [Enter] to Confirm your selection.
Press [Esc] to go back a screen.
Press [Number] Keys to input Numbers.
Press [A-Z], [Del] and [Backspace] for Text input.

```

## Logging into the DMG 7000 Web-Interface

To open the DMG 7000 web interface use one of the following supported browsers and navigate to the unit's IP address. If the login doesn't show double-check the users IP can PING the DMG over local area network. By default, the admin user account is available without a password. Press the login button in order to login to the web interface.

### Default Credentials

Username: admin

Password: (none / leave blank)

