



# Quick Start

## SLM 1479 Digital/Analog TV/Cable Analyzer



Congratulations on purchasing the SLM 1479. Follow these configuration instructions to get started. If you need assistance please contact Sencore ProCare for technical assistance.

### 1 Contents

Unpack the SLM 1479 from the box and packaging materials it was shipped in. Verify all of the following items are present:

- SLM 1479 Analyzer
- Carry Case with Shoulder Strap
- USB Cable
- AC Power Adapter
- DC Power Adapter
- User Manual/Software CD
- Antenna



If any of these items are missing or damaged, please contact Sencore to obtain replacements.

### 2 Initial Setup

Before the first use, the SLM 1479 needs to be charged for at least 12 hours.

After the initial charge has completed, use the following steps to start using your SLM 1479.

1. Press the orange HOME button to power on.
2. Press the "TV" or "CATV" button on the touch display depending on system to be tested.
3. Press the "Plan" button.
4. Use the touch wheel to scroll through channel plans and highlight the desired plan.
5. Press the "TV" or "CATV" button to select and start making measurements.
6. Press and hold the orange HOME button for 2 seconds to power down.

### 3 Making Measurements

To get started making measurements follow these steps:

1. Press the "TV" or "CATV" button.
2. Make sure the channel selection in the upper right of the display is highlighted.
3. Use the touch wheel to select the channel or touch the channel field on the display to bring up a list of channels in the selected channel plan.
4. Press the "TV" or "CATV" button repeatedly to cycle through the measurement screens.
5. Press and hold the orange HOME button for two seconds to power down the meter.